

Product data sheet

✉ sales@brannan.co.uk

☎ +44 (0)1946 816600

🌐 brannan.co.uk

MILK & COFFEE FROTHING THERMOMETERS

The milk and coffee thermometers incorporate green and red zones enabling fast and easy temperature reading of your milk or coffee and assists in making the perfect coffee, cappuccino, etc.

The thermometers are available in a choice of two probe lengths, 125mm or 175mm, with probe diameter of Ø3.8mm, and are supplied complete with a stainless steel jug mounting probe clip. The thermometers have ice test and boil test markers at 0°C and 100°C, the purpose of which being to prove that the unit is working by checking the pointer moves across the scale.

Product features:

- Celsius and Fahrenheit scale with clear zones
- Recalibration screw behind dial face
- 125mm or 175mm stainless steel probe
- Ice and boil test markers
- Jug clip

Product specifications:

Temperature range: -10 to 110°C / +20 to +220°F
Accuracy: +/-4°C
Recommended minimum immersion length: 40-50mm*
Divisions: 1°C / 2°F
CE & RoHS/WEEE: N/A
Hazard information (SDS): See brannan.co.uk for information
Product materials: Case, probe & clip: stainless steel
Scale: aluminium

Milk & coffee thermometer with 125mm probe

Product dimensions: Net: 140mm x 45mm diameter
Gross: 173mm x 50mm x 50mm

Product weights: Net: 21g
Card packaging: 14g
Gross: 56g

Milk & coffee thermometer with 175mm probe

Product dimensions: Net: 190mm x 45mm diameter
Gross: 192mm x 122mm x 50.5mm

Product weights: Net: 22g
Card packaging: 18g
Gross: 40g

Description	Barcode	Product no
125mm probe thermometer	5 011405 311504	31/150/0
175mm probe thermometer	5 011405 311511	31/151/0

* The thermometers will operate at shorter immersions, however the stated accuracy cannot be maintained.



View me on the website

