

THERM-cert range

Product data sheet

✉ sales@brannan.co.uk

☎ +44 (0)1946 816600

🌐 brannan.co.uk

PRE-CALIBRATED DIGITAL FRIDGE OR FREEZER THERMOMETER

High accuracy thermometer pre-calibrated at two fixed temperature points and part of the Brannan **THERM-cert** range. Digital thermometer to show room temperature and the temperature of fridge or freezer. The alarm sounds and the LEDs lights flash for 5 seconds every minute if the temperature goes outside the safety zone.






Product features:

- High accuracy thermometer supplied with traceable calibration certificate
- Displays fridge or freezer temperature and room temperature simultaneously
- Alarm sounds and LEDs flash if fridge or freezer temperature falls outside safe zones for food
- Large LCD
- 1m cable and suction cup for external measurement
- Adhesive pad for fixture to appliance
- Supplied with battery and full instructions

Product specifications:

Temperature range:	-40 to +70°C&F (switchable)
Resolution:	0.1°C*
Accuracy:	+1°C between 0 and +40°C, otherwise +/2°C
Calibration:	2 points @ 0 and 35°C
Battery:	1pc x AAA (supplied)
CE/ROHS/WEEE:	Compliant
Hazard information (SDS):	See brannan.co.uk for information
Probe length:	1m (with suction cup)
LCD dimensions:	58mm x 12mm
Product dimensions:	Net: 26mm x 135mm x 18mm Gross: 222mm x 164mm x 34mm
Product weight:	Net: 63g Display box: 18g Gross: 81g

TRACEABLE CALIBRATION CERTIFICATE			
ISSUED BY : S.Brannan and Sons Limited			
CALIBRATION DATE	CERTIFICATE NUMBER	SERIAL NUMBER	
<small>S. Brannan and Sons Ltd. Leicestershire Industrial Estate Cleator Road Cumbria ENGLAND CA26 3JL</small>			
 Thermometers and Gauges		<small>Telephone: +44 (0) 1946816600 Fax: +44 (0) 1946816625 E Mail: sales@brannan.co.uk Web: www.brannan.co.uk Registered No: 290512 ENGLAND</small>	
Specification: TWIN READING FRIDGE FREEZER THERMOMETER Instrument Type: ELECTRONIC THERMOMETER Range: -50/70°C&F Resolution: 0.1°C Immersion: 76mm			
Thermometer Reading	Calibration Temperature	Element Column Temperature	Standard Instrument References
19.4	0	N/A	246801/1 246801/2
17.7	35.0	N/A	246801/1 246801/2
Signed:  S. Moran		Calibration Assistant and Approved Signatory 	
<small>Laboratory Temperature 20°C +/- 5°C</small>		<small>Laboratory Humidity 20% to 90%</small>	
<small>S.Brannan and Sons operate an ISO9001 certified Quality Management System in order to ensure the accuracy and reliability of every instrument we produce. The readings were determined by comparison with traceable standard instruments, the reference numbers of which are shown above. We recommend that periodic recalibration should be carried out on this instrument yearly, but the recalibration frequency is best determined by the user depending upon the frequency and conditions of use, as well as the level of accuracy required by the process.</small>			

Description	Calibration points	Product no
THERM-cert pre-calibrated digital fridge or freezer thermometer	2 fixed points at 0 and 35°C	TC-008



Measurement for life.

